



Removing Dell Precision M65 Battery

Use this guide to remove or replace the battery.

Written By: Jay Curts



Step 1 — Battery



- Place the laptop with the front facing you.
- Turn over the computer

Step 2



- Locate the battery bay latch release.
- Slide the latch toward the back of the computer until its engaged.

Step 3



- Pull the battery tab towards the side of the computer.

Step 4



- You have removed the battery.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-25 05:45:14 AM.